optional current shunt for DM-99030, DM-9031

200 AMP CURRENT SHUNT

Model: LS-04 *ISO-9001, CE, IEC1010*







The Art of Measurement

LUTRON ELECTRONIC

200 AMP CURRENT SHUNT

Model: LS-04

Optional current shunt for DM-9030, DM-9031

SPECIFICATIONS

Range	0 - 200 Amps
Output	1 DC mV per 1 DC A
Accuracy	± (4 % + 1.5 mV)
	<i>@ 23 ± 5 ℃</i>
Application	* To cooperate with the " Car Tester "
	DM-9030, DM-9031, set the meter's
	range to DC 200 mV range, then the
	display reading will get the DCA value
	directly. For example, if the display
	reading value is 150.0 mV, then the
	exact DCA measurement value will be
	150.0 DCA.
	* To measure all kind car electric DC
	current.
Size	160 x 50 x 26 mm.
Weight	200 g.
Accessories	Operational manual 1 PC.
Included	

^{*} Appearance and specifications listed in this brochure are subject to change without notice.

0609-LS04