

Waco Digital Earth Tester (4 TERMINAL)

MODEL: WACO 4100

- DIGITAL EARTH TESTER



Features

- 4 wires earth measurement
- Soil Resistivity measurement
- Conductor resistance measurement
- 3 ½ Digit LCD Display
- Rechargeable NICD Batteries

Digital Earth Resistance Tester

Earth Ground Resistance	20/200/2000Ω
Resolution	0.1Ω
Soil resistivity	yes
Charging LED Indicator	yes
Low Battery Warning	yes
Power Source	AA1.2Vx9 rechargeable
Size	165 x 50 x 95 mm
Weight	approx. 750g

“WACO” Digital Earth Resistance Tester is direct replacement of the conventional hand generator type tester. It is designed for measurement of the resistance of earthing used in the electrical equipment as well as for measurements of ground resistivity. It can also be used for measurements of the other low regular and liquid resistance. This Instrument finds wide application for testing earthing installations in power based industries, telecommunication net-works and electrical traction systems, etc.

This is powered by rechargeable Nicd Cells, A LCD low battery indication appears when its battery goes down, which can be recharged by connecting Mains AC Supply through Charging Leads provided with the instrument.

It has 3 ½ digit Liquid Crystal display.

Its dimension are 165 x 50 x 95 mm, and weight approx 750 gms.

WACO INSTRUMENTS

32A, Ganesh.Chandra.Avenue, 4th Floor, Kolkata-700013, India.

Tel:- 91-33-22150517/22157835/22158423. Tel/Fax:- 91-33-22157835/ 91-33-23373983.

E-mail:- waco_in@yahoo.com, wacoinstruments@hotmail.com, wacoinstruments@gmail.com